

NL161
NL164
NL167

NICELITE LED BULBS FOR
MINI-MAGLITE® & SOLITAIRE
fitting instructions




NICELITE LED CONVERSION FOR SOLITAIRE & MINI-MAGLITES®

► CAUTION! TAKE CARE WHEN FITTING ◀

1. Remove the packaging by carefully sliding the polystyrene padding away from the metal bulb disc, to the left and right, as initially seen in the blister.
2. Remove batteries, unscrew and remove the head of the Solitaire or Mini-Maglite®. Grip the existing bulb and pull out.

WARNING: DO NOT LOOK DIRECTLY AT THE LED WHEN ILLUMINATED.

3. Fit the Nicelite bulb, replace the batteries and end cap to test if there is light. IF NO LIGHT, remove batteries, re-fit the Nicelite bulb at 180 degrees, and then replace the batteries and end cap. The bulb should now illuminate.
4. Remove batteries, and ensure the Nicelite bulb disc is pushed down evenly. Replace the flashlight head slowly while looking at the hole in the reflector to **ensure the LED is central** and clears the rim of the hole.
5. Finally, replace the batteries and end cap.



MORE INFORMATION:

<http://www.reflectalite.com/LEDpage.html>